



**better.**

**FOR ACCURATE MEASURING**

- 1 Measure the widest part of the penis (non-erect)
- 2 If you're between two sizes, select the smaller size
- 3 For catheter length, use the ruler to measure your penis (non-erect) from base to tip

**TO APPLY THE CATHETER**

- 1 Ensure the penis is clean and dry (no talc, lotion, etc.)
- 2 Apply the catheter to penis (non-erect)
- 3 Make sure there are no kinks or wrinkles. If you're uncircumcised do not pullback the foreskin

Measurements are close approximations.

01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24